

# 11 Placards & Markings



**BEECHCRAFT  
DUKE 60 SERIES  
MAINTENANCE MANUAL**

**CHAPTER 11**

*LIST OF PAGE EFFECTIVITY*

<b>CHAPTER SECTION SUBJECT</b>	<b>PAGE</b>	<b>DATE</b>
11-EFFECTIVITY/CONTENTS	1	Apr 18/80
11-00-00	1	Apr 18/80

**CHAPTER 11 - PLACARDS AND MARKINGS**

*TABLE OF CONTENTS*

<b>SUBJECT</b>	<b>CHAPTER SECTION SUBJECT</b>	<b>PAGE</b>
PLACARDS AND MARKINGS	11-00-00	
Description and Operation		1
Model Designation Placard		1

**"END"**



**BEECHCRAFT  
DUKE 60 SERIES  
MAINTENANCE MANUAL**

**PLACARDS AND MARKINGS - DESCRIPTION AND  
OPERATION**

in any correspondence to Beech Aircraft Corporation.

*MODEL DESIGNATION PLACARD*

NOTE

The model designation placard is located on the left side of the fuselage adjacent to the inboard end of the flap. The flaps must be lowered to observe the placard. The placard identifies the airplane by its model number and serial number. Should a question arise concerning the care of the airplane, it is important to include the airplane serial number

Ascertain that all placards are in place and legible whenever the airplane has been repainted or touched up after repairs. Replace any placards that have been inadvertently defaced after such repainting or repairs.

**"END"**

